

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
MicroQAR uQAR	165E2810-00	31-30-20	09	5/15/2018	INSTALLATION & OPERATION INSTRUCTION MANUAL	microQAR
	165E6748-01		A	8/21/2019		
612RIU	AD009A0480		Orig	2/1/1982	Installation and Maintenance Manual	
6RW105YF1	GEI-72518		Orig	9/1/1958	Operating and Maintenance Instructions	
7100 CVDR Deployable	165E6493-01	31-34-02	03	4/30/2020	Installation and Operation Instruction Manual	Cockpit Voice and Flight Data Recorder
7100 SRVIVR25	0040-28001-15	23-70-87	00	11/16/2020	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-04	23-70-71	01	2/3/2021	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-06	23-70-73	00	10/27/2020	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-05	23-70-72	01	2/3/2021	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-08	31-30-71	00	4/15/2021	Installation and Instruction Manual	Flight Data Recorder
7100 SRVIVR25	0040-28001-14	31-30-75	00	11/16/2020	Installation and Operation Manual	Flight Data Recorder
7100 SRVIVR25	0040-28001-11	31-30-74	00	9/25/2020	Installation and Operation Manual	Flight Data Recorder
7100 SRVIVR25	0040-28001-10	31-30-73	00	10/27/2020	Installation and Instruction Manual	Flight Data Recorder
7100 SRVIVR25	0040-28001-19	23-70-90	00	6/16/2021	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-12	23-70-85	00	9/25/2020	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-01	23-70-76	01	9/3/2020	Installation and Operation Manual	Cockpit Voice and Flight Data Recorder
7100 SRVIVR25	0040-28001-13	23-70-86	02	11/11/2020	Installation and Operation Manual	Cockpit Voice Recorder
7100 SRVIVR25	0040-28001-07	23-70-79	00	11/16/2020	Installation and Operation Manual	Cockpit Voice and Flight Data Recorder
	0040-28001-07	23-70-79		11/16/2020		
A100 A-100 IRIS	0040-18001-01		D	4/3/2012	Installation Manual	
AC-180A	TP-425	22-10-15	Orig	6/15/1989	Installation Manual	
ADC-4000	0040-30001-01		C	2/22/2017	Air Data Computer Installation Manual	
ADI-330A ADI-330B ADI-330C	TP-434	34-20-29	A	8/23/2017	Installation and Operation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
ADI-330D						
ADI-330E						
ADI-330F						
ADI-330G						
ADI-330H						
ADI-330J						
ADI-330K						
ADI-330L						
ADI-330M						
ADI-330N						
ADI-330P						
ADI-330R						
ADI-330S						
ADI-330T						
ADI-330U						
ADI-330V						
ADI-330W						
ADI-330Y						
ADI-331A	TP-437		A	8/31/2003	Installation and Operation Manual	
ADI-331B						
ADI-331C						
ADI-331D						
ADI-331E						
ADI-331F						
ADI-331G						
ADI-331H						
ADI-331J						
ADI-331K						
ADI-331L						
ADI-331M						
ADI-331N						
ADI-331P						
ADI-332A	TP-458	34-20-40	Reis	3/19/1998	Installation and Operation Manual	
ADI-332B						
ADI-332C						
ADI-332D						
ADI-332E						
ADI-333A	TP-445	34-20-67	A	12/23/2005	Installation and Operation Manual	
ADI-333B						
ADI-334A	TP-477	34-20-52	Reis	8/15/1994	Installation and Operation Manual	
ADI-334B						
ADI-334C						
ADI-334D						
ADI-335A	TP-490	34-20-49	C	11/24/2010	Installation and Operation Manual	
ADI-335B						
ADI-335C						
ADI-335D						

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
ADI-335E ADI-335F ADI-335G ADI-335H ADI-335J ADI-335K ADI-335L ADI-335M ADI-335N ADI-335P ADI-335R ADI-335S ADI-335T ADI-335U						
ADI-350BN	TP-532		B C1	8/30/2002	Installation and Operation Manual	
ADR-7050	0040-21453-01		L	1/6/2009	Installation Manual	
SDU Satellite Data Unit AFIRS 228S Iridium SDM Configuration Module	165E5733-02		B	6/16/2021	Installation Manual	Satellite Data Unit
SDU Satellite Data Unit 228S AFIRS 228S Iridium SDM Configuration Module	165E5733-00		04	6/16/2021	Installation Manual	Satellite Data Unit
AI-330A AI-330AA AI-330AB AI-330AC AI-330AD AI-330AE AI-330AF AI-330AG AI-330AH AI-330AK AI-330AL AI-330AP AI-330AR AI-330AS AI-330AT AI-330AU	TP-454	34-20-51	C	2/5/2018	Installation and Operation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-330AW						
AI-330AX						
AI-330AY						
AI-330AZ						
AI-330B						
AI-330BA						
AI-330BB						
AI-330BC						
AI-330BE						
AI-330BH						
AI-330BJ						
AI-330BK						
AI-330C						
AI-330D						
AI-330E						
AI-330F						
AI-330G						
AI-330H						
AI-330J						
AI-330K						
AI-330L						
AI-330M						
AI-330N						
AI-330P						
AI-330R						
AI-330S						
AI-330T						
AI-330U						
AI-330V						
AI-330W						
AI-330X						
AI-330Y						
AI-330AF	TP-480	34-20-54	A	4/3/2018	Installation and Operation Manual	
AI-330AX						
AI-340B	TP-441	34-20-32	Reis	5/20/1995	Installation and Operation Manual	
AI-340C						
AI-350AD	TP-514	34-20-65	A	9/15/2004	Installation and Operation Manual	
AI-350R						
AI-350C	TP-596		A	12/19/2003	Installation and Operation Manual	
AI-350J	TP-507	34-20-63	Orig	10/31/1996	Installation and Operations Manual	
AI-350T	TP-595		A	12/19/2003	Installation and Operation Manual	
AI-360	TP-564		E	7/12/2007	Installation and Operation Manual	
AI-360()						
AI-360	TP-625		A	11/10/2006	Installation and Operation Manual	
AI-360()						
AI-803CK	TP-537		C	2/4/2016	Installation and Operation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-803CR	TP-516	35-20-66		7/26/2005	Installation and Operation Manual	
AI-803DA	TP-590		C	2/4/2016	Installation and Operation Manual	
AI-803DJ	TP-675		D	2/4/2016	AI-803DJ Install Manual	
AI-904AZ	TP-326	34-20-02	H	9/9/2013	Installation and Operation Manual	
AI-904W						
AI-804A						
AI-804AA						
AI-804AB						
AI-804AC						
AI-804AD						
AI-804AE						
AI-804AF						
AI-804AG						
AI-804AH						
AI-804AJ						
AI-804AK						
AI-804AL						
AI-804AN						
AI-804AR						
AI-804AS						
AI-804AU						
AI-804AV						
AI-804AW						
AI-804AX						
AI-804AY						
AI-804AZ						
AI-804B						
AI-804BA						
AI-804BB						
AI-804BC						
AI-804BE						
AI-804BF						
AI-804BG						
AI-804BJ						
AI-804BK						
AI-804BL						
AI-804BN						
AI-804BP						
AI-804BT						
AI-804BU						
AI-804BV						
AI-804BW						
AI-804BY						
AI-804C						
AI-804CA						
AI-804CC						
AI-804CE						

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-804CF						
AI-804CH						
AI-804CJ						
AI-804CK						
AI-804CM						
AI-804CN						
AI-804CP						
AI-804CU						
AI-804CV						
AI-804D						
AI-804DA						
AI-804DB						
AI-804DC						
AI-804DD						
AI-804DE						
AI-804DF						
AI-804DG						
AI-804DH						
AI-804DJ						
AI-804DK						
AI-804DL						
AI-804E						
AI-804F						
AI-804G						
AI-804H/B						
AI-804H/G						
AI-804J/B						
AI-804J/G						
AI-804K						
AI-804L						
AI-804N						
AI-804P						
AI-804R						
AI-804S						
AI-804T						
AI-804U						
AI-804V						
AI-804W						
AI-804Y						
AI-804Z						
AI-904A/B						
AI-904A/G						
AI-904AA/B						
AI-904AA/G						
AI-904AB/B						
AI-904AB/G						
AI-904AC/B						
AI-904AD						

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-904AE						
AI-904AF						
AI-904AH						
AI-904AJ						
AI-904AK/B						
AI-904AK/G						
AI-904AL						
AI-904AP						
AI-904AR						
AI-904AU						
AI-904AV						
AI-904AW						
AI-904AY						
AI-904B/B						
AI-904B/G						
AI-904C/B						
AI-904C/G						
AI-904D/B						
AI-904D/G						
AI-904E/B						
AI-904E/G						
AI-904F/B						
AI-904F/G						
AI-904G/G						
AI-904H/B						
AI-904H/G						
AI-904HA/B						
AI-904HA/G						
AI-904HB/B						
AI-904HB/G						
AI-904HC/B						
AI-904HC/G						
AI-904HD/B						
AI-904HD/G						
AI-904J/B						
AI-904K/B						
AI-904L/B						
AI-904M/B						
AI-904M/G						
AI-904N/B						
AI-904N/G						
AI-904P/B						
AI-904P/G						
AI-904R/B						
AI-904R/G						
AI-904S/B						
AI-904S/G						
AI-904S/HB/B						

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-904S/HB/G AI-904T/B AI-904T/G AI-904U/B AI-904U/G AI-904U/HA/B AI-904U/HA/G AI-904U/HC/B AI-904U/HC/G AI-904V/B AI-904V/G AI-904Y/B AI-904Y/G AI-904Z/B AI-904Z/G						
AI-804CD	TP-599		C	2/4/2016	Installation and Operation	
SPS-340A SPS-341A SPS-341B SPS-341C SPS-360A SPS-360B SPS-360C SPS-360D SPS-380A SPS-380B SPS-380C SPS-380D SPS-380E SPS-600C SPS-600D SPS-600E	TP-520	27-30-10	C	8/16/2010	Installation Manual	
AN/ARN-154(V)	009-10062-001		L	9/26/2018	Installation Manual	
ANI7000	12710138B		B	3/1/1987	Installation Manual	
BC-815A	TP-350		B	6/28/2010	Installation Instructions	
AN/ARN-154(V) BTP-1634	009-10140-001		B	11/13/2003	Instruction Manual	
CD800	009-11800-001		A C1	11/6/2000	Instruction Manual	
CR2795E100A 1	GEI-36528B		B	10/1/1969	Instructions	
CA-2001A/B CA-2001A/G CA-2001B/B CA-2001B/G	TP-258		Orig	8/1/1980	Instruction Manual, Operation and Installation	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
CA-2001C/B						
CD-2001A/B						
CD-2001A/G						
CD-2001B/B						
CD-2001B/G						
CD-2001C/B						
CD-2001C/G						
DAC-2000						
DC-2001A						
DC-2001B						
DC-2001C						
DC-2001D						
DC-2001E						
DC-2001F						
DC-2001G						
DC-2001H						
DC-2001K						
FC-2001A/B						
FC-2001A/G						
FC-2001B/G						
FC-2001C/B						
FC-2001C/G						
FC-2001D/B						
FC-2001D/G						
OC-2001A/B						
OC-2001A/G						
OC-2001B/B						
OC-2001B/G						
OC-2001C/B						
OC-2001C/G						
PS-2001A						
PS-2001B						
RC-2001A						
RC-2001B						
DB682	009-10099-001		Orig	12/8/1995	Installation Manual	
DB683	009A0652		2	10/9/1995	Installation Manual	
DG-710B	TP-586		B	12/3/2003	Installation and Operation Manual	
DGS-710A	TP-429	34-20-26	Orig	12/1/1989	Installation Manual	
DGS-710B						
DME670	009A0601		Orig	1/1/1986	Installation Manual	
DME675	009A0305		C1	12/1/1990	Installation Manual	
TX675						
DU-42	0040-38501-01		D	6/2/2016	DU-42 Installation Manual	
EBDI-4000	TP-566		C	1/31/2018	Installation and Operation Manual	
EFD-750	0040-15751-01		E	7/14/2021	EFD-750 / MAG-500 Installation Manual	Electronic Flight Display
MAG-500						

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
EFI-650	13131□A907		C	5/23/2019	Installation and Operation Manual	Electronic Flight Instrument
EFI-650	0040-E57A1-01		A	9/25/2019	TroubleShooting Guide	Electronic Flight Instrument
EFI-650	13131□A908		A	5/23/2019		Electronic Flight Instrument
EHSI-4000	TP-580		B	12/6/2007	Installation and Operation Manual	
ESI-1000	0040-32001-01		U	10/13/2017	ESI-1000 Installation Manual	
ESI-2000	0040-32501-01		L	8/1/2018	ESI-2000 Installation Manual	Electronic Standby System with Battery Backup
ESI-500 MAG-500	0040-15001-01		J	2/9/2021	ESI-500 /MAG-500 Installation Manual	Solid State
ESIS-5000	0040-43001-01		F	10/13/2020	Installation Manual	Electronic Standby Instrument System with Touch Screen
LRN500	009A0631A		4	4/1/1989	Installation Manual	
2100-3083-50 2100-3083-51 2100-3084-50 CVDR FA2100 FA2100GA	165E1847-01		02	4/22/2010	FA2100CVDR Install Manual	Cockpit Voice and Data Recorder
A150 A151B A152B A55B FA2100 S055 S056 S058 S150 S151 S152 S160 S161 S162 S251 S261	165E1846-00		20	5/17/2021	FA2100CVR Install Manual	Cockpit Voice Recorder
FA2100 FDR FDR	165E1845-00		10	7/15/2021	FA2100 FDR Install Manual	Flight Data Recorder
FA2300	165E1903-05		04	12/15/2010	Installation and Operation Instruction Manual	MODULAR AIRBORNE DATA RECORDING/ACQUISITION SYSTEMS
FA2300	165E1903-36		01	8/30/2021	Installation and Operation Instruction Manual	MODULAR AIRBORNE DATA RECORDING/ACQUISITION SYSTEMS
FA2300	165E1903-24	31-31-24	02	2/28/2021	Installation and Operation Instruction Manual	MODULAR AIRBORNE DATA RECORDING/ACQUISITION SYSTEMS
FA5000	165E5327-00		03	9/10/2014	FA5000 Cockpit Voice Recorder 1/2 ATR Short Case IOM	Cockpit Voice Recorder

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
5003-6103-11 FA5000 Recorder Independent	165E5327-01		14	4/13/2020	Installation and Operation Instruction Manual	Cockpit Voice and Data Recorder
FA5000	165E6554-01		02	2/16/2021	INSTALLATION & OPERATION INSTRUCTION MANUAL	
FA5000 FA5300	165E5906-01		03	8/30/2021	Installation and Operation Instruction Manual	Cockpit Voice and Data Recorder
FA5003	165E5326-00		03	11/3/2016	FA5003- Flight Data Recorder Installation & Operartin Manual	Flight Data Recorder
FA5013	165E5850-02		INT	5/26/2016	FA5013 FDR IOM	Flight Data Recorder
FA5013	165E5850-01		INT	5/19/2016	FA5013 CVR 1/2 Short Case IOM	Cockpit Voice Recorder
ADC-3000 DCM-3000 GH-3000 MAG-3000	TP-579		E	5/1/2018	Installation and Operation Manual	
ADC-3000 DCM-3000 GH-3000AA GH-3000AB GH-3000AC GH-3000AD GH-3000AE GH-3000J GH-3000K GH-3000L GH-3000M GH-3000N GH-3000P GH-3000R GH-3000T GH-3000V GH-3000W GH-3000Y MAG-3000	TP-531		C	5/27/2009	Installation and Operation Manual	
GH-3000 GH-3000AF GH-3000AG GH-3000AH GH-3000AJ GH-3000AK GH-3000AL GH-3000AM GH-3000AN GH-3000AP GH-3000AR	TP-546		T	3/30/2017	Installation and Operation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
GH-3000AT GH-3000AU GH-3000AV GH-3000AW GH-3000AY GH-3000BA						
GH-3000A GH-3000B GH-3000C GH-3000D GH-3000E GH-3000F GH-3000G GH-3000H	TP-503	34-20-57	A	5/27/2009	Installation and Operations Manual	
GH-3000D	TP-511	34-20-60		4/29/1996	Installation and Operation	
ADC-3000 DCM-3000 GH-3001 MAG-3000	TP-530		L	6/15/2016	Installation and Operation Manual	
ADC-3000 DCM-3000 GH-3001 MAG-3000	TP-593		E	12/18/2013	Installation and Operation Manual	
DCM-3100 GH-3100 GH-3100 (2.1 software) GH-3100 (2.X Software) GH-3100 (4.X Software) MAG-3000	TP-582		G	3/4/2010	Installation and Operation Manual	
DCM-3100 GH-3100 MAG-3100	TP-559		K	3/30/2017	Installation and Operation Manual	
GH-3100	TP-629		B	3/4/2010	GH-3100 Instalation & Operation Manual (-0205)	
GH-3900 SHIS-3900	0040-34001-01		R	6/26/2017	GH-3900 (SFIS-3900) Install Manual	
GH-3900.2 KC-390	0040-34701-01		A	2/22/2017	GH-3900.2 Opertion Manaul for KC-390	
GH-3900.2	0040-34401-01		W	6/28/2021	0040-34400-01	Electronic Standby Instrument System
GH-3900RSU	0040-38001-01		D	6/2/2016	GH-3900RSU Install Manual	
GH-4001	0040-45001-01		L	2/19/2020	GH-4001 Install Manual	Electronic Standby Instrument System
GH-4001	0040-45101-01		A	3/23/2017	GH-4001 Installation & Operation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
DU-38/A GH-4200	0040-42000-01		E	3/16/2015		
9200-42000-0 201 9200-42600-0 201 DU-38/A DU-39/A GH-4200 GHR-4000	0040-42001-01		E	3/16/2015	Electronic Standby Instrument System	
HSI-3000	TP-597		0	3/17/2004	Installation and Operation Manual	
HSI-3000	TP-570		F	7/17/2017	Installation and Operation Manual	
i-linc	0040-19000-01		J	2/3/2009	Installation Manual	
JT-113A	TP-409			7/26/2005	Installation Manual	
LNS6000	009-10001-001		B	3/10/1997	Installation Manual	
LA120 LNS616 LR651 NY151 RNC601	009A0551B		0	11/1/1983	Installation Manual	
MAG-3000	TP-633		M	8/21/2019	MAG-3000 Installation Manual	
MAG-3100	0040-21200-01		J	9/5/2017	MAG-3100 Installation Manual	
PL-103A PL-103B	TP-374	24-50-04	Reis	12/15/1992	Installation Manual	
PS-823A PS-823A/T PS-823B PS-823B/T PS-823C PS-823C/T PS-823D PS-823D/T PS-823E PS-823E/T PS-823F PS-823F/T PS-823G PS-823G/T PS-823H PS-823H/T	TP-352		Orig	6/10/1987	Installation instructions	
PS-834A PS-834B	TP-447	24-30-05	B	5/8/2006	Installation and Operation Manual	
PS-835A PS-835B PS-835C	TP-336	24-30-04	P	3/20/2017	Installation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
PS-835D PS-835E PS-835F PS-835G						
PS-850A PS-850B PS-855A PS-855B PS-855C PS-855D	TP-470	24-30-07	K	8/22/2017	Installation and Operation Manual	
RGC250	009-11400-001		A C4	7/27/2000	Installation Manual	
RGC250 (enhanced interface)	009-11407-001		A	3/14/2002	Installation Manual	
RGC350	009-12400-001		A	6/25/2002	Installation Manual	
SA-151D	TP-432	22-10-17	Reis	2/28/1998	Installation Manual	
SC-841A	TP-351		A	4/5/2007	Installation Instructions	
SCD526	009-10084-001		Orig	9/16/1994	Instruction Manual	
SHSI-3000	TP-600		C	8/2/2011	Installation and Operation Manual	
SI-1000A SI-1000B SI-1000C SI-1000G SI-1000K SI-1250A SI-1500A SI-1500L SI-2500A SI-2500B SI-2500BP SI-2500LP SI-3000A SI-3000B SI-3003B SI-3003C	TP-540		F	7/22/2014	Installation and Operation Manual	
SI-100A SI-100B	TP-346		A	4/13/2007	Installation Instructions	
SI-3000A	TP-249			7/26/2005	Installation and Operation Manual	
SI-3003B	TP-310		A	8/18/2011	Installation Manual	
SI-3003C	TP-469	24-20-15	A	8/18/2011	TP-469	
SIM-3100	TP-619		A	5/22/2006	Installation and Operation Manual	
SIM-3100	TP-632		A	12/9/2009	TP-632	
SPS-341D	TP-634	27-30-13	C	8/28/2013	SPS-341D Installation Manual	
SRVIVR	0040-29001-01		03	8/18/2021	Installation and Operation Manual	Flight Data Recorder

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
SRVIVR	6081152		C	12/2/2014	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6901-01		00	10/8/2020	Installation and Operation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6379-01		B	12/20/2019	Installation and Operation Manual	Flight Data Recorder
SRVIVR	165E6358-01		A	6/13/2016	Installation and Operation Manual	SRVIVR-CVFDR-1553
SRVIVR	6082027		Orig	2/21/2014	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6702-01		A	9/11/2020	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6359-01		00	9/15/2020	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6747-01		A	5/7/2020	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6748-01		A	9/9/2019	Installation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6903-01		00	5/24/2021	Installation and Operation Manual	Flight Data Recorder
SRVIVR	165E6247-01		-	6/13/2016	Installation and Operation Manual	Cockpit Voice and Flight Data Recorder
SRVIVR	165E6578-01		A	9/21/2019	Installation and Operation Manual	Cockpit Voice and Flight Data Recorder
TRC2634 TRC-2634	0040-35001-01		J	1/9/2019	Tacan+ Installation Manual	Tactical Air Navigation System
TAWS8000	009-18001-001		G	7/28/2011	Installation Manual	
TAWS8100	009-18651-001		F	8/23/2017	Installation Manual	
TCAS791 TCAS-791 TCAS-791A	009-10013-001		H	7/18/2013	Installation Manual	
F3849 F6344 F6444 F6555 IN602 TCN970 TX970	009A0301		1	8/1/1988	Installation Manual	
TSC-1000	0040-44001-01		E	5/28/2021	TSC-1000 Install Manual	Touch Screen Controller
TSC-1000	0040-44004-01		B	9/11/2020	Remove and Replace Instructions	Touch Screen Controller
ULB Underwater Locator Beacon	165E5542-10		INT	3/11/2017	ULB Installation & Operation Manual	Flight Data Recorder
VG-204AB	TP-363		Reis	3/10/1986	Installation instructions	
VG-204AC VG-204AU VG-204D VG-204L	TP-594		C	8/22/2019	Installation Manual	Vertical Gyro
VG-204AM	TP-487	34-20-47	Orig	5/11/1994	Installation and Operation Manual	
VG-206C	TP-226		Orig	11/8/1974	Installation Instructions	
VG-206D	TP-424	34-20-08	Orig	6/15/1989	Installation Manual	
VG-208A VG-208B VG-208C	TP-270		B	9/4/2012	Installation Manual	

Install Manual Index

Last Updated: 10/18/2021 10:06:34 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
VRS-3000	TP-561		P	10/18/2016	Installation Manual	
VRS-3010	TP-592		F	10/28/2016	Installation Manual	
VRS-3020						
VRS-4000	TP-598		E	4/28/2015	Installation Manual	
WX-1000	78-8060-5815-8		D	9/30/2005	Checklist Worksheet	
WX-1000+						
WX-1000	78-8051-9150-5		H	1/9/2017	Installation Manual	
WX-1000+						
WX-1000E						
WX-10	78-8041-7921-2		Orig	7/1/1985	Installation Manual	
WX-10A						
WX-11						
WX-12						
WX-8						
WX-9						
WX-900	78-8060-6104-6		D	11/20/2001	Installation Manual	
WX-PA	78-8060-5798-6		E	7/23/2014	Instruction Manual	
WX-SM	78-8060-5874-5		G	11/11/2003	Instruction Manual	